





















<b>Comparison Chart</b> <b>Matrimatic</b> <b>Diamond series</b>  			
	<b>Bronze</b>	<b>Silver</b>	<b>Gold</b>
<b>Weight</b>	5 KG	5,6 KG	7,2 KG
<b>Dimensions</b>	36 x 19 x 27 cm	36 x 19 x 28 cm	42 x 20 x 29 cm
<b>Extension table</b>	22,5 x 34 cm	22,5 x 34 cm	38 x 51 cm
<b>Speed control</b>	Yes	Yes	Yes
<b>Needle drop position up/down</b>	Yes 	Yes 	Yes 
<b>Function with or without foot pedal Start/stop button</b>	Yes 	Yes 	Yes 
<b>Patterns (see chart)</b> <ul style="list-style-type: none"> <li>- <b>Button hole</b></li> <li>- <b>Stretch pattern</b></li> <li>- <b>Quilt pattern</b></li> <li>- <b>Decorative</b></li> <li>- <b>Cross stitch</b></li> <li>- <b>Alphabet large</b></li> <li>- <b>Alphabet small</b></li> <li>- <b>Numbers</b></li> </ul>	99 patterns <ul style="list-style-type: none"> <li>8</li> <li>10</li> <li>17</li> <li>22</li> <li>-</li> <li>Yes</li> <li>No</li> <li>Yes</li> </ul>	200 patterns <ul style="list-style-type: none"> <li>8</li> <li>10</li> <li>29</li> <li>63</li> <li>19</li> <li>Yes</li> <li>Yes</li> <li>Yes</li> </ul>	200 patterns <ul style="list-style-type: none"> <li>8</li> <li>10</li> <li>29</li> <li>63</li> <li>19</li> <li>Yes</li> <li>Yes</li> <li>Yes</li> </ul>
<b>Display</b>  	LCD :only the pattern number is show on display.  	LCD : pattern selection, length and width adjustment, advise on foot selection.  	LCD : pattern selection, length and width adjustment, advise on foot selection.  

<b>Control Panel</b>	Stitch selection by number or incremental. Adjustment of stitch length and width (limited function)	Stitch selection by number or incremental. Speed dial. Program stitch Copy / repeat stitch pattern Finishing function Adjustment of stitch length and width	Stitch selection by number or incremental. Speed dial. Program stitch combinations Copy / repeat stitch pattern Finishing function Adjustment of stitch length and width
<b>Functions</b>	Reverse stitch button Finishing button Speed control	Reverse stitch button Speed control Tie on/off button on control panel	Reverse stitch button Speed control Tie on/off button on control panel
<b>Accessories</b>	<ol style="list-style-type: none"> <li>1. Needles</li> <li>2. Bobbins</li> <li>3. Spool pin</li> <li>4. Needle plate screwdriver</li> <li>5. Screwdriver set</li> <li>6. Seam ripper and brush</li> <li>7. Button hole foot</li> <li>8. Overlock foot</li> <li>9. Zipper foot</li> <li>10. Zigzag foot</li> <li>11. Darning plate</li> </ol>	<ol style="list-style-type: none"> <li>1. Needles</li> <li>2. Bobbins</li> <li>3. Spool pin (large)</li> <li>4. Spool pin (small)</li> <li>5. Needle plate screwdriver</li> <li>6. Screwdriver set</li> <li>7. Seam ripper and brush</li> <li>8. Blind seam foot</li> <li>9. Overlock foot</li> <li>10. Zipper foot</li> <li>11. Button hole foot</li> <li>12. Zigzag foot</li> </ol>	<ol style="list-style-type: none"> <li>1. Needles</li> <li>2. Bobbins</li> <li>3. Spool pin (large)</li> <li>4. Spool pin (small)</li> <li>5. Needle plate screwdriver</li> <li>6. Screwdriver set</li> <li>7. Seam ripper and brush</li> <li>8. Blind seam foot</li> <li>9. Overlock foot</li> <li>10. Zipper foot</li> <li>11. Button hole foot</li> <li>12. Zigzag foot</li> </ol>
<b>Accessory tray</b>	Yes : removable 	Yes : removable 	Yes : removable and accessible when sewing. 
<b>Thread cutter</b>	Yes	Yes	Yes
<b>Threader</b>	Yes	Yes	Yes
<b>Light</b>	Yes	Yes	Yes extra one for needle
<b>Free arm</b>	Yes; 13,5 cm	Yes; 13,5 cm	Yes; 20 cm
<b>Thread tension control</b>	No	No	Yes
<b>Darning plate</b>	Cover with plate 	Release button 	 Release button

### Pattern selection chart Bronze model :

01	02	03	04	05	06	07	08	09	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42
43	44	45	46	47	48	49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	A	B	C	D	E	F	G
78	79	80	81	82	83	84	H	I	J	K	L	M	N
85	86	87	88	89	90	91	92	93	94	95	96	97	98
99							V	W	X	Y	Z	0	1
							2	3	4	5	6	7	8
							9						



[www.matri.eu](http://www.matri.eu)

### Pattern selection chart Silver en Gold model :

001	002	003	004	005	006	007	008	009	010	091	092	093	094	095	096	097	098	099	100
011	012	013	014	015	016	017	018	019	020	101	102	103	104	105	106	107	108	109	110
021	022	023	024	025	026	027	028	029	030	111	112	113	114	115	116				
031	032	033	034	035	036	037	038	039	040	117	118	119	120	121	122	123	124	125	126
041	042	043	044	045	046	047	048	049	050	127	128	129	130	131	132	133	134	135	136
051	052	053	054	055	056	057	058	059	060	137	138	139	140	141	142	143	144	145	146
061	062	063	064	065	066	067	068	069	070	G H I J K L M N O P									
071	072	073	074	075	076	077	078	079	080	Q R S T U V W X Y Z									
081	082	083	084	085	086	087	088	089	090	157	158	159	160	161	162	163	164	165	166
										' ? & a b c d e f									
										167	168	169	170	171	172	173	174	175	176
										g h i j k l m n o p									
										177	178	179	180	181	182	183	184	185	186
										q r s t u v w x y z									
										187	188	189	190	191	192	193	194	195	196
										[ / . - 0 1 2 3 4 5									
										197	198	199	200						
										6 7 8 9									



[www.matri.eu](http://www.matri.eu)